



Specifications

Model	Line Voltage (VAC)	Armature Voltage Range (VDC)	Continuous Armature Current (Amps)	Motor Continuous HP Range
LGM103-3	115	0 - 90	3.0	1/50 - 1/4
LGM103-10	115	0 - 90	10.0*	1/8 - 1

* Heat sink kit 223-0159 must be used when the continuous output current is over 5 amps.


AC Line Source	115 VAC ± 10%, 50/60 Hz, 1Ø
Field Voltage	50 or 100 VDC
Maximum Field Current	1 amp
Acceleration Time Range	0.5 - 10 seconds
Deceleration Time Range	coast to stop - 10 seconds
Input Impedance (S1 to S2)	>100K ohms
Analog Input Signal Range (isolated or non-isolated)	0 - 5 VDC, 0 - 10 VDC, 4 - 20 mA
Form Factor	1.37 at base speed
Load Regulation	2.0% of base speed
Speed Range	60:1
Maximum Vibration 0 - 50 Hz (>50 Hz)	0.5G (0.1G)
Surrounding Air Temperature Range	50 - 104°F / 10 - 40°C
Weight	0.85 lbs / 0.39 kg
Safety Certifications	UL/cUL Listed, File # E132235

Safety Warnings

READ ALL SAFETY WARNINGS BEFORE INSTALLING THIS EQUIPMENT

- **DO NOT INSTALL, REMOVE OR REWIRE THIS EQUIPMENT WITH POWER APPLIED.** Have a qualified electrical technician install, adjust and service this equipment. Follow the National Electrical Code and all other applicable electrical and safety codes, including the provisions of the Occupational Safety and Health Act (OSHA), when installing equipment.
- **Circuit potentials are at 115 VAC above earth ground.** Avoid direct contact with the printed circuit board or with circuit elements to prevent the risk of serious injury or fatality. Use approved personal protection equipment and insulated tools if working with power applied. Use a non-metallic screwdriver for adjusting the calibration trim pots.
- Reduce the chance of an electrical fire, shock, or explosion by using proper grounding techniques, over-current protection, thermal protection and enclosure. Follow sound maintenance procedures.
- **It is strongly recommended to install a master power switch in the line voltage input.** The switch contacts should be rated for 125 VAC and 200% of motor nameplate current.
- **Removing AC line power is the only acceptable method for emergency stopping.** Do not use braking, decelerating, or coasting to a stop for emergency stopping. They may not stop a drive that is malfunctioning.
- Line starting and stopping (applying and removing AC line voltage) is recommended for infrequent starting and stopping of a drive only. Braking, decelerating to minimum speed, or coasting to a stop is recommended for frequent starts and stops. Frequent starting and stopping can produce high torque. This may cause damage to motors.
- **Do not disconnect any of the motor leads from the drive** unless power is removed or the drive is disabled. Opening any one lead while the drive is running may destroy the drive.
- The field output is for shunt wound motors only. Do not make any connections to F1 and F2 when using a permanent magnet motor.
- Under no circumstances should power and logic level wires be bundled together.
- Be sure potentiometer tabs do not make contact with the potentiometer's body. Grounding the input may cause damage to the drive.
- This product does not have internal solid state motor overload protection. It does not contain speed-sensitive overload protection, thermal memory retention, or provisions to receive and act upon signals from remote devices for over temperature protection. If motor protection is needed in the end-use product, it needs to be provided by additional equipment in accordance with NEC standards.

Dimensions



Installation

- ### Mounting
- Components are sensitive to electrostatic discharge. Avoid direct contact with the circuit board. Hold the drive by the chassis or heat sink only.
 - Protect from dirt, moisture, and accidental contact.
 - Provide sufficient room for access to the terminal block and calibration trim pots.
 - Mount away from heat sources. Operate within the surrounding air temperature range.
 - Prevent loose connections by avoiding excessive vibration.
 - Mount in either a horizontal or vertical plane. Eight 0.19" (5 mm) wide slots in the chassis accept #8 pan head screws. Fasten either the large base or the narrow flange of the chassis to the subplate.
 - The chassis should be earth grounded. Use a star washer beneath the head of at least one of the mounting screws to penetrate the anodized chassis surface and to reach bare metal.

Heat Sinking: The LGM103-10 requires an additional heat sink when the continuous armature current is above 5 amps. Use ACE heat sink kit part number 223-0159. Use a thermally conductive heat sink compound (such as Dow Corning 340[®] Heat Sink Compound) between the chassis and the heat sink surface for optimal heat transfer.

Wiring: Use 14 - 16 AWG wire for AC line and motor wiring. Use 18 - 24 AWG wire for logic wiring.

Shielding Guidelines: As a general rule, it is recommended to shield all conductors. If it is not practical to shield power conductors, it is recommended to shield all logic-level leads. If shielding of logic-level leads is not practical, the user should twist all logic leads with themselves to minimize induced noise. It may be necessary to earth ground the shielded cable. If noise is produced by devices other than the drive, ground the shield at the drive end. If noise is generated by the drive, ground the shield at the end away from the drive. Do not ground both ends of the shield.

Fusing: LGM103-3 models contain a fast acting fuse rated for 5A at 250 VAC. LGM103-10 models contain a fast acting fuse rated for 15A at 250 VAC. Fuse is for terminal L1.

Connections

Line Input
Connect the AC line power leads to terminals L1 and L2. It is recommended to use a double-pole, single-throw master power switch. The switch should be rated at a minimum of 125 VAC and 200% of motor current.

Motor
Connect the DC armature leads to terminals A1 and A2. If the motor does not spin in the desired direction, power down the drive and reverse these connections.



Field
Connect the field leads to terminals F1 and L1 for a 50 VDC field or to F1 and F2 for a 100 VDC field.
Do not make any connections to F1 and F2 if using a permanent magnet motor.

Speed Potentiometer
Use a 10K ohm, 1/4 W potentiometer for speed control. Connect the counter-clockwise end of the potentiometer to S1, the wiper to S2, and the clockwise end to S3. If the potentiometer works inversely of desired functionality, (i.e. to increase motor speed, you must turn the potentiometer counterclockwise), power off the drive and swap the S1 and S3 connections.

Analog Input Signal Range
Instead of using a speed adjust potentiometer, LGM series drives may be wired to follow an analog input signal. This input signal can be in the form of voltage (0-10 VDC) or current (4-20 mA). Because these drives have built in isolation, the input signal can be grounded or ungrounded (floating). Connect the signal common (-) to S1 and the signal input (+) to S2.

Inhibit
If following the "Close to Inhibit" wiring, short terminals 3 and 4 to coast the motor to zero speed, open the terminals to accelerate the motor to set speed. If following the "Open to Inhibit" wiring, open terminals 4 and 5 to coast the motor to zero speed, close the terminals to accelerate the the motor to set speed. **Do not use the inhibit for emergency stopping.**

Run/Stop Switch
Wire a normally closed switch to terminals 1 and 2. Opening the switch will decelerate the motor to a minimum speed at a rate controlled by the DECEL trim pot. If no Run/Stop switch is desired, use a jumper (preinstalled). **Do not use Run/Stop switch for emergency stopping.**




Startup

SELECT SWITCHES

Signal Select (SW501)

Set the signal select switch SW501 to either CURR to use a 4-20 mA analog signal or to VOLT to use a 0-10 VDC analog signal or potentiometer.




STARTUP

- Verify that no foreign conductive material is present on the printed circuit board.
- Ensure that all switches are properly set.

1. Turn the speed adjust potentiometer full counterclockwise (CCW) or set the analog input voltage or current signal to minimum.
2. Apply AC line voltage.
3. Slowly advance the speed adjust potentiometer clockwise (CW) or increase the analog input voltage or current signal. The motor slowly accelerates as the potentiometer is turned CW or as the analog input voltage or current signal is increased. Continue until the desired speed is reached.
4. Remove AC line voltage from the drive to coast the motor to a stop.

LEDs

- Current Limit (C/LIM):** Red LED lights whenever the drive reaches current limit.
- Inhibit (INH):** Red LED lights whenever the inhibit circuit is active.
- Power (PWR):** Green LED lights whenever AC line voltage is applied to the drive.
- Run (RUN):** Green LED lights whenever the Run/Stop switch is set to Run.




Operation

DECELERATING & STOPPING

Decelerate to Minimum Speed

The switch shown below may be used to decelerate a motor to a minimum speed. Closing the switch between S1 and S2 decelerates the motor from set speed to a minimum speed determined by the MIN OUT trim pot setting. If the MIN OUT trim pot is set to zero speed, the motor decelerates to a stop, when the switch between S1 and S2 is closed. The DECEL trim pot setting determines the rate at which the drive decelerates. By opening the switch, the motor accelerates to set speed at a rate determined by the ACCEL trim pot setting.




Decelerate to Zero Speed (Coast)

See INHIBIT in the CONNECTIONS section on page 1 for a description of wiring and connection locations.

Decelerate to Zero Speed (Dynamic Brake)


Dynamic braking may be used to rapidly stop a motor. For the RUN/BRAKE switch, use a two pole, two position switch rated for at least the armature voltage rating and 150% of the armature current rating. For the dynamic brake resistor, use a 40 watt minimum, high power, wirewound resistor. Sizing the dynamic brake resistor depends on load inertia, motor voltage, and braking time. Use a lower-value, higher-wattage dynamic brake resistor to stop a motor more rapidly. Recommended value is 15 ohms for a 90 VDC motor.



REVERSING

Reversing with a Dynamic Brake

A dynamic brake may be used when reversing the motor direction. Use a three pole, three position switch rated for at least the armature voltage rating and 150% of the armature current rating. For the dynamic brake resistor, use a 40 watt minimum, high power, wirewound resistor. Sizing the dynamic brake resistor depends on load inertia, motor voltage, and braking time. Use a lower-value, higher-wattage dynamic brake resistor to stop a motor more rapidly. Recommended value is 15 ohms for a 90 VDC motor. **The motor must come to a complete stop before changing directions.**



Calibration

Minimum Speed (MIN OUT): The MIN OUT setting determines the minimum motor speed when the speed adjust potentiometer or input voltage or current signal is set for minimum speed. It is factory set for zero speed. To calibrate the MIN OUT:

1. Set the speed adjust potentiometer or input voltage or current signal for minimum speed.
2. Adjust the MIN OUT trim pot until the desired minimum speed is reached or is just at the threshold of rotation.

Maximum Speed (MAX SPD): The MAX SPD setting determines the maximum motor speed when the speed adjust potentiometer or input voltage or current signal is set for maximum speed. To calibrate the MAX SPD:

1. Set the speed adjust potentiometer or input voltage or current signal for maximum speed.
2. Adjust the MAX SPD trim pot until the desired maximum speed is reached.

Check the MIN OUT and MAX SPD adjustments after recalibrating to verify that the motor runs at the desired minimum and maximum speed.

Torque (TORQUE LIMIT): The TORQUE LIMIT setting determines the maximum torque for accelerating and driving the motor. To calibrate the TORQUE LIMIT:

1. With the power disconnected from the drive, connect a DC ammeter in series with the armature.
2. Set the TORQUE LIMIT trim pot to minimum (full CCW).
3. Set the speed adjust potentiometer or input voltage or current signal to maximum speed.
4. Carefully lock the motor armature. Be sure that the motor is firmly mounted.
5. Apply line power. The motor should be stopped.
6. Slowly adjust the TORQUE LIMIT trim pot CW until the armature current is 150% of motor rated armature current. **Continuous operation beyond this rating may damage the motor.**
7. Turn the speed adjust potentiometer CCW or decrease the input voltage or current signal.
8. Remove line power.
9. Remove the stall from the motor.
10. Remove the ammeter in series with the motor armature if it is no longer needed.

IR Compensation (IR COMP): The IR COMP setting determines the degree to which motor speed is held constant as the motor load changes. To calibrate the IR COMP:

1. Set the IR COMP trim pot full CCW.
2. Increase the speed adjust potentiometer or input voltage or current signal until the motor runs at midspeed without load. A handheld tachometer may be used to measure motor speed.
3. Load the motor armature to its full load armature current rating. The motor should slow down.
4. While keeping the load on the motor, rotate the IR COMP trim pot until the motor runs at the speed measured in step 2. If the motor oscillates (overcompensation), the IR COMP trim pot may be set too high (CW). Turn the IR COMP trim pot CCW to stabilize the motor.
5. Unload the motor.

Acceleration (ACCEL): The ACCEL setting determines the time the motor takes to ramp to a higher speed. ACCEL is factory set for the shortest acceleration time (full CCW). To calibrate the ACCEL:

1. Set the speed adjust potentiometer or input voltage or current signal for minimum speed.
2. Set the speed adjust potentiometer or input voltage or current signal for maximum speed. Measure the time it takes the motor to go from minimum speed to maximum speed.
3. If the time measured in step 2 is not the desired acceleration time, turn the ACCEL trim pot CW for a longer acceleration time, or CCW for a shorter acceleration time. Repeat steps 1 through 3 until the acceleration time is correct.

Deceleration (DECEL): The DECEL setting determines the time the motor takes to ramp to a lower speed. DECEL is factory set for the shortest deceleration time (full CCW). To calibrate the DECEL:

1. Set the speed adjust potentiometer or input voltage or current signal for maximum speed.
2. Set the speed adjust potentiometer or input voltage or current signal for minimum speed. Measure the time it takes the motor to go from maximum speed to minimum speed.
3. If the time measured in step 2 is not the desired deceleration time, turn the DECEL trim pot CW for a longer deceleration time, or CCW for a shorter deceleration time. Repeat steps 1 through 3 until the deceleration time is correct.