# Single phase, Heatsink separated type SSR

### Features

- Increase user convenience with general and small design
- Superior dielectric strength: 4,000VAC
- Improved reliability by maximizing heat protection efficiency with ceramic board
- Supports Zero cross turn-on/Random turn-on type
- Checks input status by Input LED(Green)






Please read "Caution for your safety" in operation manual before using.



## Ordering information



Model	Input voltage	Rated load current	Load voltage	Zero cross/Random turn-on		
SR1-1215	4-30VDC	454		Zono orono turn on		
SR1-4215	90-240VAC	15A				
SR1-1225	4-30VDC	054	1			
SR1-4225	90-240VAC	25A	24-240VAC			
SR1-1240	4-30VDC	404				
SR1-4240	90-240VAC	40A		Zero cross turn-on		
SR1-1250	4-30VDC	50A	1			
SR1-4250	90-240VAC	50A				
SR1-1275	4-30VDC	75A	1			
SR1-4275	90-240VAC	/ JA				
SR1-1415	4.20\/DC			Zero cross turn-on Random turn-on Zero cross turn-on		
SR1-1415R	4-30VDC	15A				
SR1-4415	90-240VAC					
SR1-1425	4.20V/DC		]	Zero cross turn-on		
SR1-1425R	4-30VDC	25A		Random turn-on		
SR1-4425	90-240VAC			Zero cross turn-on Zero cross turn-on Random turn-on		
SR1-1440	4.20V/DC		1			
SR1-1440R	4-30VDC	40A	48-480VAC			
SR1-4440	90-240VAC			Zero cross turn-on		
SR1-1450	4.00\/D0		1	Zero cross turn-on		
SR1-1450R	4-30VDC	50A		Random turn-on		
SR1-4450	90-240VAC			Zero cross turn-on		
SR1-1475	4 20V/DC		1	Zero cross turn-on		
SR1-1475R	4-30VDC	75A		Random turn-on		
SR1-4475	90-240VAC			Zero cross		

NEW

optic

(D) Proximity sensor

(E) Pressure sensor

(G) Connector/ Socket

(H) Temp. controlle

(K) Timer

(N) Display unit

(P) Switching power supply

(R) Graphic/

network device

(T) Software

I-5 **Autonics** 

# **SR1 Series**

# Specifications

### O Input

		4-30VDC input voltage	90-240VAC input voltage		
Input voltage range		4-32VDC	85-264VACrms(50/60Hz)		
Max. input current		9mA(Zero cross turn-on), 13mA(Random turn-on)	7mArms(240VACrms)		
Pick-up voltage		4VDC	85VACrms		
Drop-out voltage		1VDC	10VACrms		
Turn-on Zero cross turn-on		Max. 0.5 cycle of load source + 1ms	May 15 avale of lead course 1 1mg		
time	Random turn-on	Max. 1ms	Max. 1.5 cycle of load source + 1ms		
Turn-off time		Max. 0.5 cycle of load source + 1ms	Max. 1.5 cycle of load source + 1ms		

### Output

		24-240VAC load voltage				48-480VAC load voltage						
Load voltage range(50/60Hz)		24-264VACrms(50/60Hz)				48-528VACrms(50/60Hz)						
Rated load	Resistive load (AC-51)	15Arms	25Arms	40Arms	50Arms	75Arms	15Arms	25Arms	40Arms	50Arms	75Arms	
current Ta=25°C	Motor load (AC-53a)	_					5Arms	8Arms		15Arms		
Min. load current		0.15Arms	.15Arms 0.2Arms 0.5Arms				0.5Arms	0.5Arms				
Max. 1cycle surge current (60Hz)		190A	270A	330A	1000A		300A	500A		1000A		
Max. non-repetitive surgecurrent(I2t, t=8.3ms)		150A <sup>2</sup> S	300A <sup>2</sup> S	500A <sup>2</sup> S	4000A <sup>2</sup> S		350A2S	1000A <sup>2</sup> S		4000A <sup>2</sup> S		
Peak voltage(Non-repetitive)		600V 1200V(Zero cross turn-on), 1000V(Random						turn-on)				
Leakage current(Ta=25°C)		Max. 10mArms										
Output on voltage drop[Vpk] (Max. load current)		Max. 1.6V										
Static off-state dv/dt		500V/μs										

<sup>\*</sup> For controlling motor load, use the product which load voltage range is within 48-480VACrms.

### General Specifications

<u> </u>					
UL508, CSA22.2 No.14 and IEC/EN 60947-4-3					
4000VAC 50/60Hz 1min.(Input-Output, Input/Output-Case)					
Min. 100MΩ(at 500VDC Megger)					
green					
-30 to 80°C, Storage: -30 to 100°C(Rated load current capacity is different based on the surrounding temperature. Refer to ' ■ SSR Derating curve'.)					
ity 45 to 85%RH, storage: 45 to 85%RH					
Min. 1×0.5mm2(1×AWG 20) Max. 1×1.5mm2(1×AWG 16) or 2×1.5mm2(2×AWG 16)					
Min. 1×1.5mm2(1×AWG 16) Max. 1×6mm2(1×AWG 6) or 2×6mm2(2×AWG 10)					
0.75N·m to 0.95N·m					
1.6N·m to 2.2N·m					
Approx. 73g					
id n io					


- $\ensuremath{\mathbb{X}}$  For wiring the terminal, an O-ring terminal must be used.
- 💥 Environment resistance is rated at no freezing or condensation.

# Dimensions O Hole cut-out for panel front mounting 2-M4×0.7 TAP Fixed torque : 1.8 to 2.5N·m

I-6 Autonics


# Heatsink separated type SSR

### Connections




### ■ SSR Characteristic curve


### O SR1-1215/4215




### OSR1-1240/4240




### O SR1-1415/1415R/4415




### O SR1-1440/1440R/4440




### O SR1-1225/4225




### ○ SR1-1275/1475/1475R/4275/4475



### © SR1-1425/1425R/4425



### © SR1-1250/1450/1450R/4250/4450



(A) Photo electric

(B) Fiber optic sensor

(C) Door/Area

(D) Proximity sensor

(E) Pressure sensor

Selisoi

encoder

Connector/ Socket

(H) Temp. controller

### (I) SSR/ Power controller

Counter

(r.) Timer

Panel neter

(M) Tacho/ Speed/ Pulse

(N) Display unit

(O) Sensor

(P) Switching power supply

(Q) Stepping motor&

> (R) Graphic/ Logic

(S) Field network device

(T) Software

(U) Other

Autonics 1-7

# **SR1 Series**

### Proper usage



M High temperature caution

Make sure do not touch the heat sink or the unit body while power is supplied or right after load power is turned off. If not, it may cause a burn.

### /\ Caution for using

- 1. Attach a heatsink and ventilate for smooth convection current. If not, congested heat transfer may cause product failure or malfunction.
- 2. For mounting multiple SSR, please keep certain installation intervals for heat prevention. For horizontal installation(when the heights of input part and output part are equal), it is recommended to apply less than 50% of the rated load current.
- 3. Make sure do not touch the heatsink or the unit body while power is supplied or right after load power is turned OFF. If not, it may cause a burn.
- 4. Connect the proper cable for the rated load current with output terminal.
- 5. Use rapid fuse of which I2t is under 1/2 of SSR I2t in order to protect the unit from load's short- circuit current.
- 6. In case of a short-circuit please replace the fuse with a 1/2 of SSR I2t value specified semiconductor protective
- 7. In case that load's current is lower than SSR min. load current, connect dummy resistance to the load in parallel so as to make load's current higher than SSR min. load current.
- 8. When selecting phase control with random turn-on model, install the noise filter between load and load's source.
- 9. Make sure that the screw on output terminal is tightly fastened. Using the unit with loose bolt may cause product failure or malfunction.
- 10. Do not touch the load's terminal even if output is OFF. It may cause an electric shock.
- 11. The signal input of the 4-30VDC model should be supplied by the insulated and limited voltage/current or by Class 2 power supply.
- 12. To attach the heatsink, use Thermal Grease as below or that of equal specification.
  - ※ Thermal Grease: GE TOSHIBA(YG6111), KANTO-KASEI(FLOIL G-600), SHINETSU(G746)
- 13. Proper application environment (Avoid following environments to install)
  - ① Where temperature/humidity is beyond the specification
  - 2 Where dew condensation occurs due to temperature change
  - 3 Where inflammable or corrosive gas exists
  - 4 Where direct rays of light exist
  - (5) Where severe shock, vibration or dust exists
  - (6) Where near facilities generating strong magnetic forces or electric noise
- 14. Installation environment
  - ① It shall be used indoor
- ② Altitude Max. 2,000m
- 3 Pollution Degree 2
- 4 Installation Category III